

CZ - KOŠ FORCE HUSTÝ, PŘEDNÍ SE VZPĚRAMI**NÁVOD K MONTÁŽI PŘEDNÍHO KOŠE NA KOLO****Obsah balení**

drátěný koš
nosné vzpěry (spodní podpora)
držáky na hlavovou trubku (balení obsahuje 2 průměry)

Nářadí potřebné k montáži

křížový šroubovák
klíč na hlavové složení

Postup montáže

Postav kolo na rovnou plochu
Sundej představec
Držák s kruhovým otvorem dej pod horní matici hlavového složení
Nasaď představec
Seřď hlavové složení
Vyrovnej koš musí být vodorovně – ne nakloněný dopředu.

Údržba

Kontroluj dotažení šroubů představce
Kontroluj seřízení hlavového řízení

Záruka nemůže být uplatněna na mechanické poškození,
neodborný servisní zásah, úpravy, neodbornou montáž, nebo
nesprávné použití.

**EN - BASKET FORCE FRONT WITH HOLDER AND STAYS****FRONT BIKE BASKET ASSEMBLY INSTRUCTIONS****Package contents**

wire basket
support struts (bottom support)
head tube brackets (package includes 2 diameters)

Tools required for assembly

Phillips screwdriver
headset wrench

Assembly procedure

Place the bike on a flat surface
Remove the stem
Place the bracket with the round hole under the top nut of the headset
Install the stem
Adjust the headset
Align the basket so that it is horizontal - not tilted forward.

Maintenance

Check the tightness of the stem bolts
Check the adjustment of the headset

The warranty cannot be applied to mechanical damage,
unprofessional service intervention, modifications, unprofessional assembly, or
incorrect use.

